POLYCOM®

Polycom® KIRK® Butterfly User Guide

Version 1.1 | March, 2011 | 14211600-HD Ed.1

Trademark Information

Polycom®, the Triangles logo, ReadiManager®, SoundPoint®, SoundStation®, ViaVideo®, VoiceStation®, Vortex®, and VSX® are registered trademarks of Polycom, Inc. Convene™ , Global Management System™, iPower™, MGC™, People+Content™, People On Content™, Polycom Conference Suite™, Polycom Converged Management Application™ (CMA™), Polycom Distributed Media Application™ (DMA™), Polycom HD Voice™, Polycom PathNavigator™, Polycom VideoPlus™, Polycom VoicePlus™, PVX™, RAS™, ReadiConvene™, RMX 2000™, RSS™, V2iU™, VBP™, VS4000™, and VTX™ are trademarks of Polycom, Inc.

All other trademarks are the property of their respective owners.

Patent Information

The accompanying product is protected by one or more U.S. and foreign patents and/or pending patent applications held by Polycom, Inc.

© 2012 Polycom, Inc. All rights reserved.

Polycom, Inc.
4750 Willow Road
Pleasanton, CA 94588-2708
USA

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc. Under the law, reproducing includes translating into another language or format.

As between the parties, Polycom, Inc., retains title to and ownership of all proprietary rights with respect to the software contained within its products. The software is protected by United States copyright laws and international treaty provision. Therefore, you must treat the software like any other copyrighted material (e.g., a book or sound recording).

Every effort has been made to ensure that the information in this manual is accurate. Polycom, Inc., is not responsible for printing or clerical errors. Information in this document is subject to change without notice.

Contents

1 Getting Started 7
Handset Information 7
Charger Information 7
Battery Information 8
Battery Capacity 10
Battery Disposal 11

2 About Your Butterfly Handset 12
Handset Display 14
Status Icons 15
Display Backlight 17
Navigating Handset 17
Shortcuts 18
Personal Shortcuts 19
Predefined Shortcuts 19

3 Basic Handset Options 21
Turning Handset On/Off 21
Adjusting Speaker Volume 21
Locking/Unlocking Keypad 22
Speakerphone On/Off 22

4 Making Calls 23
Call List Calls 24
Call Register Calls 24
Corporate Directory Calls 25

5 Answering Calls 26

6 During Calls 30
Turning Speakerphone On/Off 30
Entering Phone Book 30

7 Using The Menu 31
Description of Menus 31

Phone Book 31
Call Register 31
Messages 31
MSF Function 32
External Services 32
Status 32
Settings 32
List of Menu Functions 32

8 Phone Book 34
Using the Alphanumeric Keyboard 34
Managing an Existing Contact 34

9 Call Register 39
Incoming Calls 39
Outgoing Calls 40
Missed Calls 41
Delete 42

10 Messages 44
Sending Messages Using Templates 46
Reading a Message 47
Replying a Message 48

11 Status 52
Silent 52
Auto Answer 52
Battery 52
Ringer Tone 53
Volume 53
General Information 53

12 Settings 54
Ringing Volume 54
Ringing Tone 54
Alerting Volume 55
Vibrator 55
Silent Mode 56
Changing Settings of Silent Mode 56
Auto Key Lock 56

Backlight 57
Auto Answer 58
Changing Settings of Auto Answer 58
Out of Range 58
Changing Settings of Out of Range 59
Advanced... 59
Language 59
Any Key Answer 60
Long Key 60
Login 60
Time & Date 62

13 General Information 64

Troubleshooting 64
Information 64
Error information 64
Technical Specification 65
Important Safety Instructions and Product Information 65
Intrinsic safety 66
PTC General Warning 69
Echo Cancellation 69
Compliance with New Zealand Law 69
International Regulatory and Product Information 69

Getting Started

Read all information in this section before you use your handset.

Handset Information

Never use your handset:

- in the vicinity of electrical detonators
- in shielded rooms
- in areas where radio transmission is forbidden
- in aircrafts

Do not place a handset near:

- water, moisture or damp areas
- heat sources, direct sunlight or unventilated areas
- devices which generate strong magnetic fields such as electrical appliances, fluorescent lamps, computers, radios, televisions or fax machines
- areas where the handset can be covered, its ventilation impaired, liquid spilled on the unit or objects inserted into the handset through any openings.
- areas with dust, vibration, shock or temperature extremes

Check for small metal objects in the handset earpiece/mouthpiece before using the handset.

Do not store or locate flammable liquids, gases, or explosive materials in the same compartment or vicinity as the cordless handset, its parts or accessories.

Charger Information

A micro USB charger is used to charge this handset, having the following characteristics:

- Location: Worldwide
- Part Number: 84642604

Battery Information

Read the following information before you handle the batteries:

- Do not leave a battery where it could be subjected to extremely high temperatures.
- Do not charge battery when the ambient room temperature is above 40°C/104°F or below 0°C/32°F.
- Do not replace batteries in potentially explosive environments, such as rooms where flammable liquids or gases are present.
- Do not charge batteries unless you use the approved power adaptor and the proper batteries.
- Use only Ni-MH rechargeable batteries, type AAA 1.2V in the Butterfly Handset.
- Do not dissassemble, short circuit or dispose of in fire.
- Do not mix with different battery types.
- Do not let battery or power adaptor come into contact with conductive metal objects.
- Power handset off before removing the battery.

Installing/Replacing Batteries

1 To install/replace the batteries, first remove the battery cover by using the small opening on top of the handset. Use a paperclip or a wide screwdriver.

2 When the gap at the top opens, lift off the battery cover.

3 Insert/replace the batteries. (+) and (-) symbols inside the battery compartment indicate the correct placement of the batteries.

4 Press the back cover in locked position (when you hear a click, the back cover is in position).

Note: Use only Ni-MH rechargeable batteries.

Charging Battery

During normal operation, it takes approximately 4 hours to charge the handset from fully discharged to its full capacity.

Connect handset to micro USB charger

For correct charging, be sure the room temperature is between 0°C/32°F and 40°C/104°F. Do not place the handset in direct sunlight.

If the handset is turned off, when connected to micro USB charger the handset automatically turns on.

When charging, the display shows the blue charging icon in the status bar. The charging icon is replaced by the green fully charged icon, when the batteries are fully charged (when handset is removed from the micro USB charger, the charging icon disappears).

It is necessary to recharge batteries when display shows the battery low icon, or if the handset cannot be turned on.

Battery Capacity

The capacity of the batteries depends on the use of backlight and talk time.

Batteries capacity in active mode:

- up to 15 hours active talking time.

Batteries capacity in standby mode:

- 150 hours when display backlight is set at dimmed.

For information about how to check battery capacity, refer to "Battery" on page 52.

Battery Disposal

Warning: AAA Ni-mh batteries must be disposed of properly. Do not dispose of the batteries in office or household waste.

AAA Ni-mh batteries are recyclable. You can help preserve the environment by returning your unwanted batteries to your nearest recycling center for recycling or proper disposal.

Contact your system administrator for more information about batteries disposal and recycling centers in your local area.

About Your Butterfly Handset



Table 1-1 Handset Elements

A **Speakerphone On/Off**

B **Phonebook**

C **Display**
Shows call information, handset status icons and guides you through option menus.

D **Microphone**

Table 1-2 Handset Keys

E Left Softkey

On hook (idle) On hook is the term used when handset is in standby mode.	Activates Menu function
Off hook (active) Off hook is the term used when handset is in active mode.	Mutes microphone

F Right Softkey

On hook (idle)	Takes you to Shortcuts
Off hook (active)	No function added

G On Hook

On hook (idle)	Exits menu
Off hook (active)	Ends calls

H Off Hook

Off hook (active)	Activates dial tone Swap between two calls

I Missed Call List

On hook (idle)	Navigates to Missed Call menu
Off hook (active)	Adjusts volume

J Call List/Volume Control

Table 1-2 Handset Keys

On hook (idle)	Navigates to Call List menu
Off hook (active)	Adjusts volume

K **Navigation Key**

L **Silent Mode Key**

M **Keypad Lock**

Handset Display



The display is divided in three parts: **Status Bar**, **Display Center** and **Softkey Text** (see figure above).

The types of information shown in Status Bar when:

- on hook (idle): Status Bar shows user ID, personal settings and time.
- off hook: Status Bar shows actions (“calling”, “connected”, etc.)

The types of information shown in Display Center when:

- on hook (idle): Display Center shows standby logo or call information when receiving an incoming call
- off hook: Display Center shows a telephone icon.

The types of information shown in Softkey Text when:

- on hook (idle): Softkey Text shows **Menu** and **Shortcut**.

Menu: Menu gives access to the different functions of the handset. For more information about the content of the menu, refer to "Using The Menu" on page 31. For information about how to navigate the menu, refer to "Navigating Handset" on page 17.

Shortcut: Personal shortcuts consist of functions you have chosen to add to a list of shortcuts. For more information, refer to "Personal Shortcuts" on page 19.

- off hook - display shows **Mic Mute** function.

Status Icons

The following icons may appear in Status Bar or Display Center:

Table 1-3 Handset Icons

	The low signal icon indicates that the handset soon will be out of coverage.
	The no signal icon indicates that handset is out of coverage, or that the system is busy (no speech channels available).
	The low battery icon indicates that battery capacity is low.
	The telephone icon will appear when you miss a call.
	The telephone icon will appear when an external incoming call arrives.
	The telephone icon will appear when an internal incoming call arrives

Table 1-3 Handset Icons

	The telephone icon will appear when you make a call.
	The telephone icon will appear when the handset is off hook or a call is connected.
	The envelope icon will appear when you receive a message
	The charging icon will appear when the handset is placed in charger.
	The fully charged icon will appear when the battery is fully charged.
	The key lock icon indicates that the entire keypad is locked.
	The silent icon will appear when all sounds are disabled.
	The loadspeaker icon will appear when loadspeaker is turned on
	The mute icon will appear when mic mute is turned on. Mic mute is a abbreviation of microphone mute.

Display Backlight

The display backlight automatically turns on when an incoming call or message arrives, or if a key is pressed.

The backlight turns off when the handset is idle after a preset period of time delay.

You can disable the backlight to save power, refer to "Turning Backlight Off" on page 57 for more information.

Navigating Handset

The main part of the functions of the handset are grouped into different menus. In the following sections you will find a description of how to navigate these menus. For more information about the content of the different menus, refer to "Using The Menu" on page 31.

You navigate the handset using two softkeys and a four-way navigation key. The figure below illustrates the connection between these keys and the text shown in display.

Note: The following is a description of the handset when it is on hook (idle).



Left Softkey
Pressing left softkey activates left softkey text.

Use left softkey to enter main menu. When in menu, use the key to confirm your choices.

Right Softkey
Pressing right softkey activates right softkey text.

Use right softkey to enter list of personal shortcuts. When in menu, use the key to exit menu or return to previous menu.

Four-Way Navigation Key

The handset also offers both personal and predefined shortcuts to selected functions in the menu. In the end of this chapter, you will find a section describing how to use these shortcuts.

Entering Main Menu

- To enter main menu press left softkey to activate Menu.

Scrolling in Menus

- When in menu, press top or bottom of navigation key to scroll up and down in menu.

Confirming Choices

- When in the relevant menu, press **Select** to confirm your choices. Various terms are being used in the softkey text according to the context of the specific function.

Navigating Cursor

- When in the relevant menu, press left or right side of navigation key to move cursor from side to side.This is especially relevant when you are writing/editing words or entering/editing numbers and want to delete a letter or digit.
- To delete, simply place cursor behind the letter or digit and press right softkey to activate **Delete**.

Returning to Previous Menu

- When in menu, press right softkey to activate **Back** or **Exit**. You now return to previous menu.

Leaving Menus

- To leave menu, press . This key will exit menu at once.

Shortcuts

The handset contains two types of shortcuts:

- Personal shortcuts

  Personal shortcuts consist of functions you have chosen to add to a list of shortcuts. The list is assigned to the right softkey.

- Predefined shortcuts

  Predefined shortcuts are unchangeable and assigned to different keys on the handset for quick and easy navigation to frequently used menus.

Personal Shortcuts

By adding specific functions to the list of shortcuts, you get quick access to functions you often use. The list is assigned to the right softkey.

Note: Personal shortcuts can only be used when handset is on hook (idle).

In the following, you will find a description of how to add, use and remove personal shortcuts.

To add a shortcut:

1. While on hook, press **Shortcut** to enter the shortcut function.
2. Scroll to **Edit shortcuts** and press **Select**.
3. Scroll to the function you want to make a shortcut to.
4. Press **Select** to add the function to the list of personal shortcuts.

To use a shortcut:

1. While on hook, press **Shortcut** to enter the shortcut function.
2. Scroll to the desired shortcut and press **Select**.

To remove a shortcut:

1. While on hook, press **Shortcut** to enter the shortcut function.
2. Scroll to **Edit shortcuts** and press **Select**.
3. Scroll to the desired shortcut and press **Select** to remove the function from the list of shortcuts.

Predefined Shortcuts

Predefined shortcuts are unchangeable and assigned to different keys.

In the following you will find a list of predefined shortcuts and a description of how to access and use them for quick and easy navigation to frequently used menus.

Call List: While on hook, press (-) on the left side of the navigation key to enter call list.

Incoming calls are illustrated with green arrows

Outgoing calls are illustrated with blue arrows

Missed calls are illustrated with red arrows

Exit Menu: When in menu, press **Exit**.

Phone Book Search: While on or off hook, press on the bottom of the navigation key.

Keypad Locked/Unlocked: While on hook, press **Menu** followed by * (Display shows the key lock icon) to lock/unlock keypad.

Missed Calls: While on hook, press (+) on the right side of the navigation key to enter a list of missed calls.

Save Contact: While on hook, enter number and press **Save**.

Silent On/Off: Press **Menu** followed by **#** to turn the handset silent mode on/off. In silent mode the ringer will be muted and the vibrator activated (Display shows the silent icon followed by the text **Silent mode on/off**, and a small icon is placed in status line).

Speed Dial: While on hook, press digit equivalent to number of the contact in the speed dial list continuously until call is started.

Basic Handset Options

Turning Handset On/Off

To turn handset on:

- Press to turn handset on.

To turn handset off:

1 Press until the question **Turn off?** appears in display.

2 Press **Yes** to confirm.

Note: The handset will automatically turn on if connected to a charger.

Note: It is not possible to turn off the handset if it is connected to a charger.

Note: When you turn handset off, all content of call register and settings of time and date are deleted if the subscribed system does not resend the information to the handset.

Adjusting Speaker Volume

Adjusting speaker volume can only be done when handset is off hook. The handset will remember the speaker volume until you make a new adjustment.

During a telephone conversion you can adjust the speaker volume at any time in relation to the noise level of the surrounding environment.

To turn speaking volume up:

- While off hook, press (+) on the navigation key to turn volume up.

To turn speaker volume down:

- While off hook, press (-) on the navigation key to turn volume down.

Locking/Unlocking Keypad

Lock keypad to prevent keys from being accidentally pressed.

To lock/unlock keypad:

- Press **Menu** followed by * to lock keypad.
- Press **Unlock** followed by * to unlock keypad.

To answer a call when keypad is locked, press . When you end the call, the keypad automatically locks.

For automatic keypad lock, refer to "Auto Key Lock" on page 56.

Speakerphone On/Off

To enable/disable speakerphone

- While on a call, press on the navigation key to enable speakerphone.
- To disable speakerphone, press .
- While idle, press to hook off and to enable speakerphone.

Making Calls

The handset must be subscribed and registered to make a call. For more information about subscribing, refer to "Creating a Login" on page 61.

For internal calls, dial extension number. Contact your system administrator for a list of these extension numbers.

For external calls, dial external code (or line pool code) to access an external line, then dial external number. Contact your system administrator to confirm what external code or line pool code to use.

Off Hook Dialling (Dial Directly)

1. Press to get dial tone.
2. Dial the extension or external number.
3. Press to terminate the call.

On Hook Dialling (Pre-Dial)

1. Dial the extension or external number.
2. Press to make a call.
3. Press to terminate the call.

Dial from Phone Book

The handset's local phone book is intuitive to operate. The find name function makes it easy to find a contact as you can jump directly to the desired contact using the quick search as described below.

1. Press **Menu** to enter main menu.
2. Scroll to **Phone Book** and press **Select**.
3. Scroll to **Find name** and press **Select**.
4. To find a name you can:
   - Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.
   - Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).
5. Press to make a call.

6 If more than one number: scroll to the desired number and press .

7 The display icon appears until call is connected.

8 Press to terminate the call.

Note: For more information about using your phone book, refer to "Phone Book" on page 34.

Call List Calls

Call list shows up to 40 of your latest incoming, outgoing and missed calls. When memory of call list is full, the handset will automatically erase the oldest call when a new call is received in call list.

- Incoming calls are illustrated with green arrows
- Outgoing calls are illustrated with blue arrows
- Missed calls are illustrated with red arrows

To dial from call list:

1 While on hook, press left side of navigation key to enter call list.

2 Scroll to the desired name or number and press .

Note: When you turn off the handset, all content of call list is deleted if the subscribed system does not resend the information to the handset.

Call Register Calls

The call register menu stores up to 40 of your incoming, outgoing and missed calls. The calls are classified in three groups: incoming calls, outgoing calls and missed calls.

If memory of call register is full, the handset will automatically erase the oldest call when a new call is received in call register. If you want to delete calls from call register manually, refer to "Delete" on page 42.

To dial from call register list:

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to the desired list and press **Select**.

4 Scroll to the desired name or number and press .

For more information about call register, refer to "Call Register" on page 39.

Note: When you turn off the handset, all content of call register is deleted if the subscribed system does not resend the information to the handset.

Redial

1. Press **Menu** to enter main menu.
2. Scroll to **Call register** and press **Select**.
3. Scroll to **Outgoing calls** and press **Select**.
4. Scroll to the desired name or number and press .

Speed Dial Calls

If you have assigned a number to one of the speed-dialing keys 0-9, do the following:

- While on hook, press digit equivalent to number of the contact in the speed dial list continuously until call is started.

  Note: For more information about adding number to speed dial, refer to "Adding to Speed Dial" on page 36.

Corporate Directory Calls

To dial from the corporate directory list, the External Services in the handset menu must be selected.

External Services are features placed in the main system, and only available if the handset is subscribed to a KIRK solution.

The corporate directory is a common phone book for all handsets subscribed to the actual system, and all handsets subscribed to the system are listed in this corporate directory. Additional numbers can be added to the phone book by the system administrator.

To dial from corporate directory list

1. Press **Menu** to enter the main menu.
2. Scroll to **External Services** and then press **Select**.
3. Press the left (-) or right (+) side of the navigation key to scroll to find the name or spell the name out using the keys (2-9).
4. When the desired name is displayed, press to dial the number.

Answering Calls

The handset must be subscribed and registered to answer a call. For more information about subscribing, refer to "Creating a Login" on page 61.

When handset rings, display shows the icon for incoming calls and the caller information appears below if supported by the subscribed system.

- Press to answer a call when your handset rings.

  Note: You can distinguish between an internal and external call by the ring tone. The ring tone of an internal call is followed by three short beeps (system dependent feature).

Auto Answer

When auto answer is turned on, the handset automatically goes off hook when an incoming call arrives.

If subscribed to a wireless solution, the handset automatically goes on hook when calls are terminated.

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Auto answer** and press **Select**.
4. Scroll to **On** or **Off** and press **Change**.
5. Scroll to **Settings**, press **Change** and press **Select** to activate/deactivate loudspeaker.

   Note: When charging, auto answer is inactive.

Mute a Call

- Press **Silence** and the ring signal is muted.

End a Call

- Press and the call is ended.

Reject a Call

- Press **Reject** to refuse the call. The rejected call is registered as a missed call.

Note: When subscribed to KIRK Wireless Server 1500, KIRK Wireless Server 600v3, KIRK Wireless Server 500, KIRK Wireless Server 8000 analogue or KIRK Wireless Server 2500 analogue, it is not possible to reject an incoming call. To reject a second incoming call, see Call Waiting.

Call Transfer (Blind)

Note: Transfering a call (Blind) is system dependent. If supported by the subscribed system, do the following:

1. While on a call, press .

   -or-

   While on a call, press **Hold** and then press **New call.**
2. Dial the extension or external number.
3. Press **Transfer** to send the call through and to hang up.

Note: When subscribed to KIRK Wireless Server 1500, KIRK Wireless Server 600v3, KIRK Wireless Server 500, KIRK Wireless Server 8000 analogue or KIRK Wireless Server 2500 analogue, do the following:

1. While on a call, press .
2. Dial the extension or external number.
3. Press to send the call through and to hang up.

Call Transfer (Attended)

Note: Transfering a call (Attended) is system dependent. If supported by the subscribed system, do the following:

1. While on a call, press .-or-

   While on a call, press **Hold** and then press **New call**.
2. Dial the extension or external number.
3. Press .
4. When the other caller answers, press **Transfer** to send the call through and to hang up.

Note: When subscribed to KIRK Wireless Server 1500, KIRK Wireless Server 600v3, KIRK Wireless Server 500, KIRK Wireless Server 8000 analogue or KIRK Wireless Server 2500 analogue, do the following:

1. While on a call, press .
2. Dial the extension or external number.
3. When the other caller answers, press to send the call through and to hang up.

Call Hold

Note: Call Hold is system dependent. If supported by the subscribed system, do the following:

1. To place an active call on hold, press **Hold**.
2. To retrieve the call, press **Resume**.

Note: When subscribed to KIRK Wireless Server 1500, KIRK Wireless Server 600v3, KIRK Wireless Server 500, KIRK Wireless Server 8000 analogue or KIRK Wireless Server 2500 analogue, do the following:

1. To place an active call on hold, press .
2. To retrieve the call, press .

Call Waiting

Note: Call Waiting is system dependent. If supported by the subscribed system, do the following:

1. While on a call, press **Accept** to answer a second incoming call. The first call will automatically be put on hold.
2. To reject a second incoming call, press **Reject**.
3. To disconnect the active call and return to the waiting call, press .
4. To end both calls, press twice.

Note: To swap between two calls, press .

-or-

To swap between two calls, press **Options**, scroll to **Swap Calls** and press **Select**.

Note: When subscribed to KIRK Wireless Server 1500, KIRK Wireless Server 600v3, KIRK Wireless Server 500, KIRK Wireless Server 8000 analogue or KIRK Wireless Server 2500 analogue, do the following:

1. While on a call, press to answer a second incoming call. The first call will automatically be put on hold.
2. To reject a second incoming call, press the left side of the navigation key (-) for three seconds.
3. To disconnect the active call, press , and to return to the waiting call, press .
4. To end both calls, press .

Note: To swap between two calls, press .

Call Forward Unconditional

Note: Call Forward Unconditional is system dependent. If supported by the subscribed system, do the following:

1. To enable CFU press ***21*** followed by a number, then press **#**.

2 Press to enable CFU. Confirmation in display and a tone indicates that the feature has been activated.

3 Press to hang up.

4 To disable CFU, press **#21#**, then press .

5 Press to hang up.

Note: *21* code can be changed in the KIRK Wireless Server to fit your standard.

During Calls

When you are on a call, you have three options as described in the following. Two of the options concern whether you want to make parts of a call public or personal. It is possible to turn both of these options on at the same time. The last and third option is to enter and use the phone book, while you are on a call.

Turning Speakerphone On/Off

Turning loudspeaker on allows other people in the room to listen to and participate in the conversation. You may set the handset on a desk or table and leave your hands free.

To turn speakerphone on/off:

1. While on a call, press on the navigation key to enable speakerphone.
2. To disable speakerphone, press .
3. While idle, press to hook off and to enable speakerphone.

Turning Microphone Mute On/Off

Turning microphone mute on will mute your voice. That is you can hear the other party but they cannot hear you.

1. While on a call, press **Mic Mute** to turn microphone mute on.
2. To turn microphone mute off, press **Mic on**.

Entering Phone Book

While on a call, you can access the find name function to scroll through names and numbers using the up/down navigation key. For more information about entering phone book, refer to "Predefined Shortcuts" on page 19. For more information about using phone book, refer to "Phone Book" on page 34.

Using The Menu

The handset offers a range of functions that are grouped into menus. The main menu consists of seven menus: Phone Book, Call register, Messages, MSF Function, External services, Status and Settings.

For more information about accessing and navigating the menu, refer to "Navigating Handset" on page 17.

Note: If handset is in menu mode, and an incoming call arrives, then menu will be dropped and the call handled as usual. When call is terminated, the handset returns to menu mode.

Description of Menus

In the following, you will find a short description of the seven menus. For more information about a specific menu, see reference in the end of each description or "List of Menu Functions" on page 32, which will give you a quick overview of the functions of each menu.

Phone Book

You can store numbers and names in your phone book.

The phone book can store up to 50 names with up to four numbers each. A maximum of 24 digits, including spaces, is allowed for each number. Names are sorted alphabetically starting with their first character.

For more information about using phone book, refer to "Phone Book" on page 34.

Call Register

The call register keeps track of all your recent calls as it stores up to 40 of your incoming, outgoing and missed calls.

For more information about call register, refer to "Call Register" on page 39.

Messages

If supported by the subscribed system, you can send and receive messages from the messages menu.

All messages are automatically stored in the inbox or outbox. Messages can store up to 8 messages. A maximum of 72 letters, including spaces, is allowed for each message.

For more information about reading, writing and sending messages, refer to "Messages" on page 44.

MSF Function

MSF Function is a special function based on MSF (Message Service Function). The function requires special software in the main system.

External Services

To dial from the corporate directory list, the External Services in the handset menu must be selected.

External Services are features placed in the main system, and only available if the handset is subscribed to a KIRK solution.

The corporate directory is a common phone book for all handsets subscribed to the actual system, and all handsets subscribed to the system are listed in this corporate directory. Additional numbers can be added to the phone book by the system administrator.

Status

Status provides a quick overview of some of the handset settings and works as a shortcut, which makes it easy to change the basic settings according to your needs. For more information about changing basic settings, refer to "Status" on page 52.

Settings

Settings offer you the opportunity to customize the handset according to your needs. The settings can be changed at any time.

For more information about customizing the handset, refer to "Settings" on page 54 or "Advanced..." on page 59.

List of Menu Functions

In the following you will find a list of the different menu functions. The list gives a quick overview where to find the desired function of the handset.

Phone Book

1. Find name
2. Add name/number
3. Speed dial

4 Delete

Call Register

1 Incoming calls

2 Outgoing calls

3 Missed calls

4 Delete

Messages

1 New message

2 Inbox

3 Outbox

4 Erase messages

5 Templates

MSF Function

1 Number:

External services

Status

1 Silent

2 Auto answer

3 Battery

4 Ringing tone

5 Volume

6 General information

Settings

1 Ringing volume

2 Ringing tone

3 Alerting volume

4 Vibrator

5 Silent mode

6 Auto key lock

7 Backlight

8 Auto answer

9 Out of range

10 Advanced...

Phone Book

You can store numbers and names in your phone book.

The phone book can store up to 50 names with four numbers each. A maximum of 24 digits, including spaces, is allowed for each number. Names are sorted alphabetically starting with their first character.

If the display shows **Memory full**, it is necessary to delete one or more names from the phone book (refer to "Deleting Contact" on page 37).

Using the Alphanumeric Keyboard

The normal dialling keys (0-9) are used for writing the name to be placed in the phone book. By pressing the keys a certain number of times the related letters will appear in the display.

Spaces are made by using the 0 -key.

Key ✱ changes between uppercase and lowercase letters, which is indicated on the top left-hand corner of the display.

Pressing left (-) or right (+) side of navigation key will move the cursor.

To delete letters, place cursor behind letter and press **Delete**.

Managing an Existing Contact

The phone book menu offers a range of possibilities to manage existing contacts and makes it easy to add, edit or delete name and number.

Note: It is possible to add up to four numbers to a contact.

Finding Contact in Phone Book

The handset's local phone book is intuitive to operate. The find name function makes it easy to find a contact as you can jump directly to the desired contact using the quick search as described below.

1. Press **Menu** to enter main menu.
2. Scroll to **Phone Book** and press **Select**.
3. Scroll to **Find name** and press **Select**.
4. To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

5 It is also possible to reach **Find name** option by pressing 🕮 on the bottom of the navigation key.

Dialing Contact from Phone Book

To dial from phone book, refer to "Dial from Phone Book" on page 23.

Editing Name/Number

You can edit name and number of a contact in phone book at any time.

1 Press **Menu** to enter main menu.

2 Scroll to **Phone Book** and press **Select**.

3 Scroll to **Find name** and press **Select**.

4 To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

5 Press **Details**.

6 If more than one number: scroll to the desired number and press **Select**.

7 Scroll to **Edit name/number** and press **Select**.

8 Edit **Name** using the digits 0-9 (refer to "Using the Alphanumeric Keyboard" on page 34).

9 Scroll to **Number** and edit number using the digits 0-9.

10 Press **Save** to store your changes.

Adding New Number

You can add a new number to a contact in phone book at any time. It is possible to add up to four numbers to each contact.

1 Press **Menu** to enter main menu.

2 Scroll to **Phone Book** and press **Select**.

3 Scroll to **Find name** and press **Select**.

4 To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

5 Press **Details.**

6 If more than one number, press **Select**.

7 Scroll to **Add new number** and press **Select**.

8 Enter the new number using the digits 0-9 and press **Save**.

9 Repeat step 7-8 to add another number to the contact.

Adding to Speed Dial

You can assign a number to one of the speed-dialing keys 0-9. This way you only need to press a single digit to find name and number of the contact, you want to phone.

Note: A maximum of 10 speed dial numbers is allowed.

For more information about making a call using speed dial, refer to "Speed Dial Calls" on page 25.

1 Press **Menu** to enter main menu.

2 Scroll to **Phone Book** and press **Select**.

3 Scroll to **Find name** and press **Select**.

4 To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

5 Press **Details.**

6 If more than one number: scroll to the desired number and press **Select**.

7 Scroll to **Add to speed dial** and press **Select**.

8 Scroll to the desired position and press **Add name**.

9 If position is occupied, press **Yes** to replace existing speed dial.

Deleting Number

You can delete a single number at any time and still keep the rest of the belonging numbers of a contact. If you want to delete a contact and all belonging numbers, refer to "Deleting Contact" on page 37.

1 Press **Menu** to enter main menu.

2 Scroll to **Phone Book** and press **Select**.

3 Scroll to **Find name** and press **Select**.

4 To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

5 Press **Details**.

6 If more than one number: scroll to the desired number and press **Select**.

7 Scroll to **Delete number** and press **Select**.

8 Press **Ok** to confirm.

Deleting Speed Dial

Use this function to delete a speed dial number, or replace it with a new speed dial when necessary. For more information about replacing a speed dial, refer to "Adding to Speed Dial" on page 36.

1 Press **Menu** to enter main menu.

2 Scroll to **Phone Book** and press **Select**.

3 Scroll to **Delete** and press **Select**.

4 Scroll to **Speed dial number** and press **Select**.

5 Scroll to the desired speed dial number and press **Delete**.

Deleting Contact

Use the delete name and number function if you want to delete a contact and all the belonging numbers. If you only want to delete a single number and keep the contact and the rest of the belonging numbers, refer to "Deleting Number" on page 36.

1 Press **Menu** to enter main menu.

2 Scroll to **Phone Book** and press **Select**.

3 Scroll to **Find name** and press **Select**.

4 To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

5 Press **Details.**

6 If more than one number, press **Select**.

7 Scroll to **Delete name/number** and press **Select**.

8 Press **OK** to confirm.

Adding New Contact (max 50)

Use the Add name/number function when you want to add a new contact to phone book.

Note: It is possible to add up to four numbers to a contact.

1 Press **Menu** to enter main menu.

2 Scroll to **Phone Book** and press **Select**.

3 Scroll to **Add name/number** and press **Select**.

4 Type the name of the contact using the digits 2-9 (refer to "Using the Alphanumeric Keyboard" on page 34).

5 Scroll to number and enter the number to be stored (max. 24 digits).

6 Press **Save** to store name and number.

Note: If display shows **Memory full**, it is necessary to delete one or more contacts from phone book (refer to "Deleting Contact" on page 37).

Call Register

The call register menu can store up to 40 of your incoming, outgoing and missed calls. Call register is divided into lists of: incoming calls, outgoing calls and missed calls.

If memory of call register is full, the handset will automatically erase the oldest call when a new call is received in call register. If you want to delete calls from call register manually, refer to "Delete" on page 42.

Note: When you turn off the handset, all content of call register is deleted if the subscribed system does not resend the information to the handset.

Incoming Calls

Incoming call is a list of all your incoming calls sorted by date and time of the call, starting with the latest call.

If name and number of incoming call already exits in your phone book, the incoming call will be represented with the name of the contact. If name and number do not exist in your phone book, the handset cannot recognize the number and the incoming call will only be represented by the number.

In both cases, incoming call register provides details about incoming calls, such as time, date and length of conversation**.**

It is possible to add name and number of an incoming call to phone book or to delete an incoming call from the list.

Viewing List of Incoming Calls

1. Press **Menu** to enter main menu.
2. Scroll to **Call register** and press **Select**.
3. Scroll to **Incoming calls** and press **Select**.

Adding an Incoming Call to Phone Book

If you have an incoming call and the number is not in phone book it is possible to add it to phone book from the incoming call list.

1. Press **Menu** to enter main menu.
2. Scroll to **Call register** and press **Select**.
3. Scroll to **Incoming calls** and press **Select**.

4 Scroll to the desired call and press **Details**.

5 Press **Options**.

6 Scroll to **Add to phone book** and press **Select**

7 Write the name of the contact using the digits 0-9 (refer to "Using the Alphanumeric Keyboard" on page 34) and press **Save**.

Deleting an Incoming Call from List

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Incoming calls** and press **Select**.

4 Scroll to the desired call and press **Details**.

5 Press **Options** and scroll to **Delete from list**.

6 Press **Select** to confirm.

Outgoing Calls

Outgoing calls is a list of all your outgoing calls sorted by date and time of the call, starting with the latest call.

If name and number of the outgoing call already exits in your phone book, the outgoing call will be represented with the name of the contact. If name and number do not exist in your phone book, the handset cannot recognize the number and the outgoing call will only be represented by the number.

In both cases, outgoing call register provides details about outgoing calls, such as time, date and length of conversation**.**

It is possible to add name and number of an outgoing call to your phone book, or to delete an outgoing call from the list.

Viewing List of Outgoing Calls

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Outgoing calls** and press **Select**.

Adding an Outgoing Call to Phone Book

If you have made a call and the number is not in phone book, it is possible to add it to phone book from the outgoing call list.

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Outgoing calls** and press **Select**.

4 Scroll to the desired call and press **Details**.

5 Press **Options.**

6 Scroll to **Add to phone book** and press **Select**.

7 Write the name of the contact using the digits 0-9 (refer to "Using the Alphanumeric Keyboard" on page 34) and press **Save**.

Deleting an Outgoing Call from List

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Outgoing calls** and press **Select**.

4 Scroll to the desired call and press **Details**.

5 Press **Options** and scroll to **Delete from list.**

6 Press **Select** to confirm.

Missed Calls

Missed calls is a list of all your missed calls sorted by date and time of the call, starting with the latest call.

If the name and number of the missed call already exits in your phone book, the missed call will be represented with the name of the contact. If the name and number do not exist in your phone book, the handset cannot recognize the number and the missed call will only be represented by the number.

In both cases, missed call register provides details about missed calls, such as time, date and length of conversation**.**

It is possible to add name and number of a missed call to your phone book or to delete a missed call from the list.

Viewing List of Missed Calls

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Missed calls** and press **Select**.

Adding a Missed Call to Phone Book

If you have a missed call and the number is not in phone book, it is possible to add it to phone book from the missed call list.

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Missed calls** and press **Select**.

4 Scroll to the desired missed call and press **Details.**

5 Press **Options**.

6 Scroll to **Add to phone book** and press **Select**.

7 Write the name of the contact using the digits 0-9 (refer to "Using the Alphanumeric Keyboard" on page 34) and press **Save**.

Deleting a Missed Call from List

1 Press Menu to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Missed calls** and press **Select**.

4 Scroll to the desired missed call and press **Details.**

5 Press **Options** and scroll to **Delete from list.**

6 Press **Select** to confirm.

Delete

The call register menu can store up to 40 of your incoming, outgoing and missed calls. If the memory of call register is full, the handset will automatically erase the oldest call when a new call need to be stored in the call register.

If you want to erase manually, use the following delete functions to empty lists in the call register.

Deleting All Incoming Calls

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Delete** and press **Select**.

4 Scroll to **Incoming calls** and press **Select**.

5 Press **Yes** to empty list.

Note: If you only want to delete a single incoming call, see "Deleting an Incoming Call from List" on page 40.

Deleting All Outgoing Calls

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Delete** and press **Select**.

4 Scroll to **Outgoing calls** and press **Select**.

5 Press **Yes** to empty list.

Note: If you only want to delete a single outgoing call, see "Deleting an Outgoing Call from List" on page 41.

Deleting All Missed Calls

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Delete** and press **Select**.

4 Scroll to **Missed calls** and press **Select**.

5 Press **Yes** to empty list.

Note: If you only want to delete a single missed call, see "Deleting a Missed Call from List" on page 42.

Deleting All Calls from All Lists

1 Press **Menu** to enter main menu.

2 Scroll to **Call register** and press **Select**.

3 Scroll to **Delete** and press **Select**.

4 Scroll to **All calls** and press **Select**.

5 Press **Yes** to empty all folders.

Messages

If supported by the subscribed system, you can write, send and receive messages from the messages menu. You write messages using the alphanumeric keyboard. For more information, refer to "Using the Alphanumeric Keyboard" on page 34.

All messages are automatically stored in inbox or outbox.

The inbox is a list of all received messages, while outbox is a list of all sent messages. Both lists are sorted by time and date, starting with the latest.

If the name and number of the message already exits as a contact in your phone book, the message in the inbox or outbox will be represented with the name of the contact. If the name and number do not exists in your phone book, the handset cannot recognize the number and the message will only be represented by the number.

If you save a message in outbox for later handling, the message will be represented by the beginning of the text message.

Inbox and outbox can store up to 8 messages in total. A maximum of 72 letters, including spaces, is allowed for each message.

If the memory of inbox and outbox is full, the handset will automatically erase the oldest message when a new message need to be stored.

If you want to delete messages from inbox or outbox manually, refer to "Erasing a Single Message" on page 50, "Erase All Read Messages from Inbox" on page 50, "Erase All Messages from Inbox" on page 51, "Erase All Messages from Outbox" on page 51 and "Erase All Messages" on page 51.

Writing and Sending a New Message

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **New message** and press **Select**.
4. Write a message.
5. Optionally, you can use a template: Press **Options**, scroll to **Use template**, press **Select**, scroll to desired template, press **Options,** scroll to **Select** and press **Select**. For more information about templates, refer to "Saving a New Message as a Template" on page 45, "Saving a Received Message as a Template" on page 46, "Sending Messages Using Templates" on page 46 and "Erasing a Single Template" on page 50.
6. Press **Options** and scroll to **Send**.

7 Press **Select** and then press **Search** to find the receiver**.**

8 To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

9 Press **Select**.

10 If more than one number: scroll to desired number.

11 Press **Select** and then press **Send**.

12 When the message has been sent, the envelope icon will appear. Press **Ok** to accept.

Clearing Text Field

Use the clear text function, when you are writing a new message and want to start all over.

1 Press **Options**.

2 Scroll to **Clear text** and press **Select**.

Saving a New Message in Outbox

You can write a message and then save it in outbox for later handling.

1 Press **Menu** to enter main menu.

2 Scroll to **Messages** and press **Select**.

3 Scroll to **New message** and press **Select**.

4 Write a message and press **Options**.

5 Scroll to **Save message** and press **Select**.

6 Scroll to **Outbox** and press **Select**.

Saving a New Message as a Template

After writing a message you can save it as a template for later use.

1 Press **Menu** to enter main menu.

2 Scroll to **Messages** and press **Select**.

3 Scroll to **New message** and press **Select**.

4 Write a message and press **Options**.

5 Scroll to **Save message** and press **Select**.

6 Scroll to **Templates** and press **Select**.

7 If memory is full: press **Ok.**

8 Scroll to the desired position and press **Select.**

Saving a Received Message as a Template

You can save a message from inbox as a template for later use.

1 Press **Menu** to enter main menu.

2 Scroll to **Messages** and press **Select**.

3 Scroll to **Inbox** and press **Select**.

4 Scroll to desired message and press **Select**.

5 Press **Options**.

6 Scroll to **Forward** and press **Select**.

7 Press **Options**.

8 Scroll to **Save message** and press **Select**.

9 Scroll to **Templates** and press **Select**.

Sending Messages Using Templates

You can create up to 8 templates in relation to the kind of message you often need to send. To create a new template, refer to "Saving a New Message as a Template" on page 45 and "Saving a Received Message as a Template" on page 46.

When using a template in a message you have two options:

- Use a template from the very beginning of the process (see below).
- Insert a template in a message when you are in the process of writing a message (refer to "Writing and Sending a New Message" on page 44).

To use a template in a message:

1 Press **Menu** to enter main menu.

2 Scroll to **Messages** and press **Select**.

3 Scroll to **Templates** and press **Select**.

4 Scroll to the desired template and press **Option**.

5 Scroll to **Select** and press **Select**.

6 If relevant, write additional text.

7 Press **Options.**

8 Scroll to **Send** and press **Select.**

9 Press **Search** to find the receiver.

10 To find a name you can:

— Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.

— Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).

11 Press **Select.**

12 If more than one number: scroll to desired number.

13 Press **Select** and then press **Send**.

Reading a Message

In addition to the messages for general use as described in this chapter, you can receive other types of messages. These types of messages cannot be sent from your handset, but are sent from an external application. The external applications may vary from system to system. For more information, please contact your system administrator.

Examples of messages sent from an external application are:

- Messages can have up to a length of 72 characters and are saved in the inbox of the handset. If supported by the subscribed system, you can also write and send this type of messages from your handset.
- Call back messages - also contain contact information.

In the following, you will find a description of how to read the messages.

The envelope icon , the text message and the contact information (if available) will appear in the display when you receive a message. Scroll up and down presssing top or bottom of the navigation key to read the entire message.

To remove the message form the display:

- Press **OK.**

  Note: The message is stored in inbox.

To act on the call back message:

- Press to call the call back number in the message.

To delete the call back message:

1 Press **Menu** to enter main menu.

2 Scroll to **Messages** and press **Select**.

3 Scroll to **Inbox** and press **Select**.

4 Scroll to the desired call back message and press **Select**.

5 Press **Options**.

6 Scroll to **Erase** and press **Select**.

7 Click **Yes** to "**Erase message?"**

Replying a Message

When you want to reply to a message from your inbox, you have three options:

- Write a new message in an empty screen
- Write in continuation of original text (received message)
- Insert a template

Reply Using an Empty Screen

1 Press **Menu** to enter main menu.

2 Scroll to **Messages** and press **Select**.

3 Scroll to **Inbox** and press **Select**.

4 Scroll to the desired received message and press **Select.**

5 Press **Options**.

6 Scroll to **Reply** and press **Select**.

7 Scroll to **Empty screen** and press **Select**.

8 Write a message and press **Options**.

9 Scroll to **Send** and press **Select**.

10 Press **Send**.

Reply in Continuation of Original Text

Note: Original text refers to the received text message.

1 Press **Menu** to enter main menu.

2 Scroll to **Messages** and press **Select**.

3 Scroll to **Inbox** and press **Select**.

4 Scroll to the desired received message and press **Select.**

5 Press **Options**.

6 Scroll to **Reply** and press **Select**.

7 Scroll to **Original text** and press **Select**.

8 Write a message in continuation of received message and press **Options**.

9 Scroll to **Send** and press **Select**.

10 Press **Send**.

Reply Using a Template

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Inbox** and press **Select**.
4. Scroll to the desired message and press **Select.**
5. Press **Options**.
6. Scroll to **Reply** and press **Select**.
7. Scroll to **Template** and press **Select**.
8. Scroll to the desired template and press **Options**.
9. Scroll to **Select** and press **Select**.
10. If relevant, write additional text.
11. Press **Options**.
12. Scroll to **Send** and press **Select**. Then press **Send**.

Forwarding a Message

If you want to forward a message to a contact, do the following:

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Inbox** and press **Select**.
4. Scroll to the desired received message and press **Select**.
5. Press **Options**.
6. Scroll to **Forward** and press **Select**.
7. Press **Option** and then press **Send**.
8. Press **Search** to find the receiver.
9. To find a name you can:
   - Scroll until you reach the desired name. To scroll through the names quickly press the navigation key continuously.
   - Use quick search by pressing the first letter(s) (max. 5 letters) of the desired name (refer to "Using the Alphanumeric Keyboard" on page 34).
10. Press **Select**.
11. If more than one number: scroll to desired number.
12. Press **Select** and then press **Send**.

Resending a Message

If you want to resend a message to a contact, do the following:

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Outbox** and press **Select**.
4. Scroll to the desired message and press **Select**.
5. Press **Options**.
6. Scroll to **Resend** and press **Select**.
7. Press **Options**.
8. Scroll to **Send** and press **Select**.
9. Press **Send**.

Erasing a Single Template

Use this function to delete a template, or replace the template with a new template when the memory is full. For more information about replacing a template, refer to "Saving a New Message as a Template" on page 45.

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Templates** and press **Select**.
4. Scroll to the desired template and press **Options**.
5. Scroll to **Erase** and press **Select**.
6. Press **Yes** to "**Erase message?**"

Erasing a Single Message

The handset will automatically erase the oldest message when the memory of inbox and outbox is full (refer to "Messages" on page 44).

If you want to delete a message manually, do the following:

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Inbox** or **Outbox** and press **Select**.
4. Scroll to the desired message and press **Select**.
5. Press **Options**.
6. Scroll to **Erase** and press **Select**.
7. Press **Yes** to "**Erase message?**"

Erase All Read Messages from Inbox

Use this function to erase all read messages from inbox. This way you do not risk erasing messages that you have not had time to read yet.

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Erase messages** and press **Select**.
4. Scroll to **All read** and press **Select**.
5. Press **Yes** to "**Erase all read messages from Inbox?**"

Erase All Messages from Inbox

Use this function to erase all messages from inbox.

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Erase messages** and press **Select**.
4. Scroll to **Inbox** and press **Select**.
5. Press **Yes** to "**Erase all messages from Inbox?"**

   Note: If you only want to erase a single message from inbox, refer to "Erasing a Single Message" on page 50.

Erase All Messages from Outbox

Use this function to erase all messages from your outbox.

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Erase message**s and press **Select**.
4. Scroll to **Outbox** and press **Select**.
5. Press **Yes** to "**Erase all messages from Outbox?"**

   Note: If you only want to erase a single message from the outbox, see "Erasing a Single Message" on page 50.

Erase All Messages

Use this function to erase all messages from inbox and outbox. If you want to be sure not to erase unread messages, refer to "Erase All Read Messages from Inbox" on page 50.

1. Press **Menu** to enter main menu.
2. Scroll to **Messages** and press **Select**.
3. Scroll to **Erase messages** and press **Select**.
4. Scroll to **All** and press **Select**.
5. Press **Yes** to "**Erase all messages from all folders?**"

Status

The status menu provides an overview of some of the handset settings and works as a shortcut to these making it easy to change the settings according to your needs. The status menu also provides information about battery capacity.

In the following you will find a description of the settings to be found in the status menu.

Silent

When silent mode is turned on, the handset will not ring when a call arrives. However, you will still be able to see the arriving call in the display.

For more information about changing settings for silent mode, refer to "Silent Mode" on page 56.

Auto Answer

When auto answer is turned on, the handset automatically goes off hook when ringing.

If subscribed to a wireless solution, the handset automatically goes on hook when calls are terminated.

For more information about changing settings for auto answer, refer to "Auto Answer" on page 58.

Battery

The battery function shows remaining battery capacity.

The indication on the display is not necessarily an exact reflection of the remaining speech time, but only an indication of the voltage on the battery.

To check remaining battery capacity:

1. Press **Menu** to enter main menu.
2. Scroll to **Status** and press **Select**.

Ringer Tone

The ring tone is followed by a number indicating the chosen tone of the ringer.

You can distinguish between an internal and external call by the ring tone. The ring tone of an internal call is followed by three short beeps (system dependent feature).

For more information about changing ring tone, refer to "Ringing Tone" on page 54.

Volume

Adjusts ringing volume according to the noise level of the surrounding environment.

For more information about adjusting ringing volume, refer to "Ringing Volume" on page 54.'

General Information

General handset information about:

- IPEI number of the handset
- Software version
- Hardware version
- Part number (item number)
- Product ID (P-ID)
- Regulatory model number (if available)

Settings

The setting menu offers you the opportunity to customize the handset according to your needs. The settings can be changed at any time. The setting menu consists of: Ringing volume, Ringing tone, Alerting volume, Vibrator, Silent mode, Auto key lock, Backlight, Auto answer, Out of range and Advanced settings.

Note: Advanced settings are described separately in the next chapter.

In the following you will find a description of how to customize the handset.

Ringing Volume

To adjust the volume of the ring tone:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Ringing volume** and press **Select**.
4. Press left (-) or right (+) side of navigation key to adjust the volume of the ring tone.
5. Press **Set**.

Ringing Tone

The ring tone is followed by a number indicating the chosen tone of the ringer.

You can distinguish between an internal and external call by the ring tone. The ring tone of an internal call is followed by three short beeps (system dependent feature).

To choose a new ring tone:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Ringing tone** and press **Select**.

4 Scroll to the desired ring tone and press **Change** to select and listen to the chosen ring tone. Repeat the process if you want to choose and listen to other ring tones.

Alerting Volume

Alerts are short beeps that appear when:

- You receive a new message.
- You send a message.
- The handset is moving out of range.
- The handset is out of range.
- The battery capacity is low.
- You create a login.

To adjust alerting volume:

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Alerting volume** and press **Select**.

4 Press the left (-) or right (+) side of the navigation key to adjust the volume of the ringer.

5 Press **Set.**

Vibrator

When vibrator is turned on, the handset will vibrate when an incoming call arrives.

To turn vibrator on/off:

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Vibrator** and press **Select**.

4 Scroll to **On** or **Off** and press **Change**.

Note: When charging, handset will not vibrate.

Silent Mode

When silent mode is turned on, the handset will not ring when a call arrives. However, you will still be able to see the arriving call in the display.

To turn silent mode on/off:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Silent mode** and press **Select**.
4. Scroll to **On** or **Off** and press **Change**.

Note: It is also possible to turn Silent mode on or off without entering menu. While on hook, press **Men**u followed by #. In silent mode the ringer will be muted and the vibrator activated.

Note: When activating silent mode, the vibrator will spin shortly.

Changing Settings of Silent Mode

When silent mode is turned on, you can select other ways of indicating incoming calls or messages:

- Display flashing

  When turned on, the display will flash when an incoming call or message arrives.

- Vibrator

  When turned on, the handset will vibrate when an incoming call or message arrives.

- Short ring

  When turned on, a short ring will appear when an incoming call arrives.

To change settings of silent mode:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Silent Mode** and press **Select**.
4. Scroll to **Settings** and press **Change**.
5. Scroll to the desired setting and press **Select**.

Auto Key Lock

Use auto key lock to prevent keys from being accidentally pressed.

With auto keylock turned on the handset will automatically lock keypad after 30 seconds. To manually lock/unlock keypad, press **Menu** followed by ✱.

To turn auto key lock on/off:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Auto key lock** and press **Select**.
4. Scroll to **On** or **Off** and press **Change**.

To answer a call when auto key lock is on, press . When you end the call, keypad automatically locks.

Backlight

The display backlight automatically turns on when an incoming call or message arrives, or a key is pressed.

The backlight turns off when handset is in standby mode after a preset period of time delay.

Setting Backlight at Dimmed

When setting display backlight at dimmed, display information can still be seen vaguely when handset is in standby mode.

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Backlight** and press **Select**.
4. Scroll to **Dimmed** and press **Change**.

Turning Backlight Off

Turning display backlight off when handset is in standby mode will save battery power.

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Backlight** and press **Select**.
4. Scroll to **Off** and press **Change**.

Adjusting Backlight Delay

You can adjust the period of time before backlight turns off when handset is in standby mode.

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Backlight** and press **Select**.
4. Scroll to **Delay** and press **Change**.
5. Press left (-) and right (+) side of navigation key to adjust backlight delay.
6. Press **Set**.

Auto Answer

When auto answer is turned on, the handset automatically goes off hook when an incoming call arrives.

If subscribed to a wireless solution, the handset automatically goes on hook when calls are terminated.

1. To turn auto answer on/off:
2. Press **Menu** to enter main menu.
3. Scroll to **Settings** and press **Select**.
4. Scroll to **Auto answer** and press **Select**.
5. Scroll to **On** or **Off** and press **Change**.

Note: When charging, auto answer is inactive.

Changing Settings of Auto Answer

When auto answer is turned on, you can select if the handset should automatically go off hook and turn on the loudspeaker.

To change settings of auto answer:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Auto answer** and press **Select**.
4. Scroll to **Settings** and press **Change**.
5. Scroll to the desired setting and press **Select**.

Out of Range

The out of range indicator appears when handset is moving out of or already is out of range of base station.

Note: When the handset has been outside the coverage area, it can take up to 30 seconds before the handset is back on the system after re-entering coverage area.

To turn out of range on/off:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Out of range** and press **Select**.
4. Scroll to **On** or **Off** and press **Change**.

Changing Settings of Out of Range

The handset offers two types of out of range alerts:

- Icon only
- Tone (beep) + icon

With the out of range indicator turned on:

- If handset is moving out of range, the low signal icon will appear in display.
- If the handset gets out of range, the no signal icon will appear in display. If tone + icon is selected, beeps will appear with short intervals as long as the handset is out of range.

To change the settings:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Out of range** and press **Select**.
4. Scroll to **Settings** and press **Change**.
5. Scroll to the desired alert and press **Select**.

Advanced...

In the setting menu it is also possible to define the following advanced settings: Language, Any Key Answer, Long Key, Login and Time& Date.

Language

There are 14 predefined languages in the handset: Czech, Danish, German, English, Spanish, French, Italian, Dutch, Norwegian , Polish, Portuguese, Russian, Finnish and Swedish.

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Advanced** and press **Select**.
4. Scroll to **Language** and press **Select**.
5. Scroll to the desired language and press **Select**.

Any Key Answer

When turned on, you can answer a call by pressing any key.

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Advanced** and press **Select**.
4. Scroll to **Any key answer** and press **Select**.
5. Scroll to **On** or **Off** and press **Change**.

Long Key

The long key function supports system features and defines a long key press to digits between 0-9. The long key press can be defined as speed dials (refer to "Speed Dial Calls" on page 25) or as MSF messages. MSF messages are system dependent. If supported by the subscribed system, a MSF message sent to the system could for example return system features to the handset.

To change long key definition:

1. Press **Menu** to enter main menu.
2. Scroll to **Settings** and press **Select**.
3. Scroll to **Advanced** and press **Select**.
4. Scroll to **Long key** and press **Select**.
5. Scroll to desired definition and press **Change**.

Login

Before you can use the registered handset it is necessary to subscribe the handset to a system (login). The handset can be subscribed to up to 2 different systems. To subscribe to a system, refer to "Creating a Login" on page 61.

Selecting a Login

If you want to change to another system manually, do the following:

1. Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Login** and press **Select**.

5 Scroll to **Select Login** and press **Select**.

6 Scroll to the desired login and press **Select**.

Removing a Login

Logins can be removed from the system in use and from the other system (if connected).

Note: Removing a login requires a password. Password is factory set at 0000.

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Login** and press **Select**.

5 Scroll to **Remove login** and press **Select**.

6 Scroll to the desired login and press **Select**.

7 Enter your password and press **Ok**.

8 If the system in use is removed, it is necessary to select one of the remaining systems or to subscribe to a new one.

Note: If one of the systems not chosen is removed, the handset remains connected to the system in use.

Creating a Login

To create a login, the system must allow subscriptions to be made. Some systems also require an Authentication Code (AC). If more than one system currently permits subscription, you will need to know the ID of the system to which you want to subscribe. Authentication Codes and system ID's will be provided be the system administrator.

You can subscribe up to 2 systems, that is create 2 logins.

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Login** and press **Select**.

5 Scroll to **Create login** and press **Select**. The handset will start searching for a system.

6 Scroll to the found system and press **Select**.

7 If required, enter an AC Code and press **Ok** to connect to the system.

8 Press **Ok**.

Note: If the handset is already subscribed to 2 systems, you will have to remove a subscription before creating a new subscription (refer to "Removing a Login" on page 61).

Selecting Login Automatically

When auto login is turned on, the handset automatically changes to another system when necessary. Auto login should only be used when systems are separate, with no overlaps.

Note: To activate auto login your handset must be subscribed to at least two systems.

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Login** and press **Select**.

5 Scroll to **Auto login** and press **Select**.

6 If **Off** is selected, press **Change** to select **On**.

The handset automatically selects a system. The selected system is marked with an A.

Time & Date

Note: When you turn off the handset, the settings of time are deleted if the subscribed system does not resend the information to the handset.

Choose Time Format

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Time & date** and press **Select**.

5 Scroll to **Time format** and press **Select**.

6 Scroll to desired time format and press **Change**.

Choose Date Format

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Time & date** and press **Select**.

5 Scroll to **Date format** and press **Select**.

6 Scroll to desired date format and press **Change**.

Change Time

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Time & date** and press **Select**.

5 Scroll to **Change time** and press **Select**.

6 Place cursor on the digit, you want to change.

7 Press a digit. The cursor will then automatically jump to the next digit.

8 Press **Change**.

Change Date

1 Press **Menu** to enter main menu.

2 Scroll to **Settings** and press **Select**.

3 Scroll to **Advanced** and press **Select**.

4 Scroll to **Time & date** and press **Select**.

5 Scroll to **Change date** and press **Select**.

6 Scroll to desired date format and press **Change**.

7 Place cursor on the digit, you want to change.

8 Press a digit. The cursor will then automatically jump to the next digit.

9 Press **Change**.

General Information

Troubleshooting

The handset freezes.

- Remove and replace batteries. Press to turn on the handset.

The handset does not ring.

- Check whether **Silent mode** is turned **On**.

The handset cannot find a system ID at Create Login.

- Check whether the system is set to allow subscriptions.

The handset cannot subscribe even if system ID has been found.

- Check if Authentication Code is necessary.

Not possible to turn on the handset.

- Check if batteries are connected. If yes, charge the batteries.

The handset turns off when receiving a call and going off-hook.

- Charge the batteries. If still a problem change the batteries as they might be defective.

Information

Error information

Improper function of the handset might be related to the infrastructure to which the handset is connected to.

Before declaring a handset for repair be sure that the main system is operating properly.

Technical Specification

Approvals

Access profile: EN 300 444 V1.4.1:2002

EMC: EN 301 489 - 1: Version 1.6.1

EN 301 489 - 6: Version 1.2.1

Radio: EN 301 406 V1.5.1

Safety: EN 60950 - 1:2006

Size and weight

Size: 150 x 50 x 20 mm/5.9 x 1.96 x 0.78 in

Weight: 105 gr/3.55 oz incl. batteries

Capacity

Active talking time up to 15 hours

Stand-by time up to 150 hours

Temperature and air pressure

Operating temperature incl. charging: 0-40°C/32-104°F

Important Safety Instructions and Product Information

Before using your telephone equipment, you should always follow basic safety instruction to reduce the risk of fire, electrical shock and injury to persons, and damage to property.

1. Read and understand all instructions
2. Follow all warnings and instructions including those marked on the product
3. Unplug this product before cleaning. Do not use liquid cleaners or aerosol cleaners. Use damp cloth for cleaning
4. Do not install the telephone equipment in the bathroom or near a wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool
5. Slots or openings in the equipment are provided for ventilation to protect it from over-heating. These openings must not be blocked or covered.
6. Do not overload wall outlets and extension cords as this can result in fire or electrical shock.
7. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in fire, electrical shock, or injury. Never spill liquid of any kind into this product.

8. To reduce the risk of electrical shock or burns, do not disassemble this product. Opening or removing covers may expose you to dangerous voltages, dangerous electrical current, or other risks. Incorrect reassemble can cause electrical shock when the appliance is subsequently used. If the product need repair, consult your dealer.
9. Refer servicing to qualified service personnel.
10. Avoid using telephone during an electrical storm. There may be a risk of electrical shock from lightning.
11. Do not use the telephone to report a gas leak in the vicinity of the leak
12. Do not place the base or charger near microwave ovens, radio equipment, or non-ground connected televisions. These appliances may cause electrical interference to the base or handset.
13. This telephone will not operate in the event of a blackout. Please keep a backup phone for emergencies.
14. Installation must be performed in accordance with all relevant national wiring rules.
15. Plug acts as Disconnect Device - The socket outlet to which this apparatus is connected must be installed near the equipment and must always be readily accessible.
16. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.
17. Warning - The earpiece/mouthpiece region on the handset can attract and retain small metallic objects.

Intrinsic safety

Do not use the handset in conditions where there is a danger of electrically ignited explosions.

Exposure to sunlight, heat and moisture

Do not expose the cordless phone to direct sunlight for long periods. Keep the cordless phone away from excessive heat and moisture.

Spare parts and accessories

Use only approved spare parts and accessories. The operation of non-approved parts cannot be guaranteed and may even cause damage.

Power failure

In the event of a power failure or flat battery, you cannot use the handset to make or receive calls

Battery Precautions

1. Exercise care in handling batteries in order not to short the batteries with conducting materials such as rings, bracelets, and keys. The batteries or conducting material may overheat and cause burns or fire.
2. Do not open or mutilate the batteries, released electrolyte is corrosive and may cause damage to the eyes or skin. The electrolyte may be toxic of swallowed.

3 During charging batteries heat up. This is normal and not dangerous.

4 Battery installation Caution - Danger of Explosion if Battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Notices

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas

EMCCautions: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

If your telephone equipment causes harm to the telephone network, the telephone company may ask you to disconnect the system from the line until the problem has been corrected or they may discontinue your service temporarily. If possible, they will notify you in advance, But if advance notice is not practical, you should be notified as soon as possible. You will be informed of your right to file a complaint with the FCC.

Your telephone company may make changes in its facilities, equipment, operations, or procedures that could affect the proper functioning of your telephone system, If they do and it is possible, you will be notified in advance to give you an opportunity to maintain uninterrupted telephone service. If you experience trouble with this telephone system, disconnect it from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to local regulations. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

FCC Note: This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC ID: M72-PKBK001.

SAR: Device has been tested for SAR compliance for head and body worn configurations. The highest reported SAR values are: head 0.00981 W/kg and body worn 0.020 W/kg.

IC Note: Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
The Term "IC": before the certification/registration number only signifies that the Industry Canada technical specifications were met.
Privacy of communications may not be ensured when using this telephone. IC number: 1849C-PKBK001.

Power Outage: In the event of a power outage, your cordless telephone will not operate. The cordless telephone requires electricity for operation. You should have a telephone which does not require electricity available for use during power outages.

Information to user: The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note EMC: Cet appareil a été soumis à un essai et jugé conforme aux normes régissant les limites établies pour un dispositif numérique de classe B, conformément aux règlements locaux.Ces limites visent à assurer une protection raisonnable contre des interférences pouvant nuire à l'appareil utilisé dans un secteur résidentiel. Cet équipment génère et utilise des radiofréquences, et peut en émettre. S'il n'est pas installé et utilisé selon les directives fournies, il risque de perturber les radiocommunications. L'exploitation de cet appareil dans un secteur particulier est toutefois susceptible de produire des interférences nuisibles. Si cet équipement provoque des interférences lors de la réception des radiofréquences ou des fréquences de télévision, ce qui peut être vérifié en mettant l'appareil hors tension, puis en le remettant sous tension, l'utilisateur doit prendre l'une des mesures suivantes pour corriger la situation:

— réorienter ou relocaliser l'antenne de réception;
— augmenter la distance entre l'appareil et l'antenne de réception;
— brancher l'appareil à une prise d'un circuit différent de celui auquel l'antenne est branchée;
— consulter le détaillant ou un technicien en radiotélévision d'expérience pour obtenir de l'aide.

PTC General Warning

The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.

Echo Cancellation

Echo cancellers are not normally required in the Telecom PSTN because gegraphic delays are acceptable where CPE return loss is maintained within Telepermit limits. However, those private networks making use of Voice over IP technology are required to provide echo cancellation for all voice calls. The combined effect of audio/VoIP conversion delay and IP routing delay can cause the echo cancellation time of 64 mS or more to be required.

Compliance with New Zealand Law

The Ministry of Economic Development (MED) Radio Spectrum Management (RSM) requires that Polycom Asia Pacific PTE limited have an approved Supplier Declaration of Conformity (Sdoc) listing the EMC, the electrical safety and all other test reports required for compliance in New Zealand.

Note: Telecom Access Standards has not seen the EMC or the Radio Spectrum test reports used by Polycom Asia Paciific limited to prove MED RSM conformity.

http://www.rsm.govt.nz/cms/importers-and-exporters/suppliers

International Regulatory and Product Information

Table 1-4 CE

CE	The KIRK Butterfly Handset has been marked with the CE mark. This mark indicates compliance with EEC Directives 1999/5/EC. A full copy of the Declaration of conformity can be obtained from Polycom Ltd, 270 Bath Road, Slough, Berkshire, SL1 4DX, UK.

Table 1-5 1999/5/EF

Cesky [Czech]:	Polycom (UK) Ltd tímto prohlašuje, že tento KIRK Butterfly Handset je ve shode se základními požadavky a dalšími príslušnými ustanoveními smernice 1999/5/ES.
Dansk [Danish]:	Undertegnede Polycom (UK) Ltd erklærer herved, at følgende udstyr KIRK Butterfly Handset overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Deutsch [German]:	Hiermit erklärt Polycom (UK) Ltd, dass sich das Gerät KIRK Butterfly Handset in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Eesti [Estonian]:	Käesolevaga kinnitab Polycom (UK) Ltd seadme KIRK Butterfly Handset vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.
English:	Hereby, Polycom (UK) Ltd. declares that this KIRK Butterfly Handset is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Español [Spanish]:	Por medio de la presente Polycom (UK) Ltd declara que el KIRK Butterfly Handset cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Ελληνική [Greek]:	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Polycom (UK) Ltd ΔΗΛΩΝΕΙ ΟΤΙ KIRK Butterfly Handset ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
Français [French]:	Par la présente Polycom (UK) Ltd déclare que l'appareil KIRK Butterfly Handset est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.
Italiano [Italian]:	Con la presente Polycom (UK) Ltd dichiara che questo KIRK Butterfly Handset è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Íslenska (Icelandic):	Hér með lýsir Polycom (UK) Ltd yfir því að KIRK Butterfly Handset er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC
Latviski [Latvian]:	Ar šo Polycom (UK) Ltd deklare, ka KIRK Butterfly Handset atbilst Direktivas 1999/5/EK butiskajam prasibam un citiem ar to saistitajiem noteikumiem.
Lietuviu [Lithuanian]:	Šiuo Polycom (UK) Ltd deklaruoja, kad šis KIRK Butterfly Handset atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Table 1-5 1999/5/EF

Nederlands [Dutch]:	Hierbij verklaart Polycom (UK) Ltd dat het toestel KIRK Butterfly Handset in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Malti [Maltese]:	Hawnhekk, Polycom (UK) Ltd, jiddikjara li dan [il-mudel tal-prodott] jikkonforma mal-htigijiet essenzjali u ma provvedimenti ohrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.
Magyar [Hungarian]:	Alulírott, Polycom (UK) Ltd nyilatkozom, hogy a KIRK Butterfly Handset megfelel a vonatkozó alapvetõ követelményeknek és az 1999/5/EC irányelv egyéb elõírásainak.
Norsk [Norwegian]:	Polycom (UK) Ltd erklærer herved at utstyret KIRK Butterfly Handset er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.
Polski [Polish]:	Niniejszym Polycom (UK) Ltd oswiadcza, ze KIRK Butterfly Handset jest zgodne z zasadniczymi wymaganiami oraz innymi stosownymi postanowieniami Dyrektywy 1999/5/WE
Português [Portuguese]:	Polycom (UK) Ltd declara que este KIRK Butterfly Handset está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.
Slovensko [Slovenian]:	Polycom (UK) Ltd izjavlja, da je ta KIRK Butterfly Handset v skladu z bistvenimi zahtevami in ostalimi relevantnimi dolocili direktive 1999/5/ES.
Slovensky [Slovak]:	Polycom (UK) Ltd týmto vyhlasuje, že KIRK Butterfly Handset splna základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.
Suomi [Finnish]:	Polycom (UK) Ltd vakuuttaa täten että KIRK Butterfly Handset tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.
Svenska [Swedish]:	Härmed intygar Polycom (UK) Ltd att denna KIRK Butterfly Handset står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Table 1-6 Explosive Device Proximity Warning

	Warning Do not operate your wireless network device near unshielded blasting caps or in an explosive environment unless the device has been modified to be especially qualified for such use.

Table 1-7 Explosive Device Proximity Warning

Waarschuwing	**Gebruik dit draadloos netwerkapparaat alleen in de buurt van onbeschermde ontstekers of in een omgeving met explosieven indien het apparaat speciaal is aangepast om aan de eisen voor een dergelijk gebruik te voldoen.**
Varoitus	**Älä käytä johdotonta verkkolaitetta suojaamattomien räjäytysnallien läheisyydessä tai räjäytysalueella, jos laitetta ei ole erityisesti muunnettu sopivaksi sellaiseen käyttöön.oen.**
Attention	**Ne jamais utiliser un équipement de réseau sans fil à proximité d'un détonateur non blindé ou dans un lieu présentant des risques d'explosion, sauf si l'équipement a été modifié à cet effet.**
Warnung	**Benutzen Sie Ihr drahtloses Netzwerkgerät nicht in der Nähe ungeschützter Sprengkapseln oder anderer explosiver Stoffe, es sei denn, Ihr Gerät wurde eigens für diesen Gebrauch modifiziert und bestimmt.**
Avvertenza	**Non utilizzare la periferica di rete senza fili in prossimità di un detonatore non protetto o di esplosivi a meno che la periferica non sia stata modificata a tale proposito.**
Advarsel	**Ikke bruk den trådløse nettverksenheten nært inntil uisolerte fenghetter eller i et eksplosivt miljø med mindre enheten er modifisert slik at den tåler slik bruk.**
Aviso	**Não opere o dispositivo de rede sem fios perto de cápsulas explosivas não protegidas ou num ambiente explosivo, a não ser que o dispositivo tenha sido modificado para se qualificar especialmente para essa utilização.**
¡Advertencia!	**No utilizar un aparato de la red sin cable cerca de un detonador que no esté protegido ni tampoco en un entorno explosivo a menos que el aparato haya sido modificado con ese fin.**
Varning!	**Använd inte den trådlösa nätverksenheten i närheten av oskyddade tändhattar eller i en explosiv miljö om inte enheten modifierats för att kunna användas i sådana sammanhang.**

Table 1-8 WEEE Marking

	The WEEE Marking on this equipment indicates that the product must not be disposed of with unsorted waste, but must be collected separately. Visit www.polycom.com/batteries for further guidance on battery recycling.

Polycom® Product Warranty Statement

The software included in this Product (including, without limitation, firmware and all updated thereto, including any software that may be downloaded electronically via the internet or otherwise (the "Software") is licensed, not sold. Customer shall not reverse compile, disassemble or otherwise reverse engineer, embed within any other software product, or modify in any manner with respect thereto, the Software in whole or in part.

THE TERMS AND CONDITIONS APPLICABLE TO POLYCOM'S LIMITED WARRANTY ARE AS SET FORTH BELOW (AND ARE ALSO INCLUDED IN THE DOCUMENTATION PACKAGED WITH NEW POLYCOM PRODUCTS):

LIMITED WARRANTY. Polycom warrants to the end user ("Customer") that the product will be free from defects in workmanship and materials, under normal use and service, for one year, or such longer period as Polycom may announce publicly from time to time for particular products, from the date of purchase from Polycom or its authorized reseller. Polycom's sole obligation under this express warranty shall be, at Polycom's option and expense, to repair the defective product or part, deliver to Customer an equivalent product or part to replace the defective item, or if neither of the two foregoing options is reasonably available, Polycom may, in its sole discretion, refund to Customer the purchase price paid for the defective product. All products that are replaced will become the property of Polycom. Replacement products or parts may be new or reconditioned. Polycom warrants any replaced or repaired product or part for ninety (90) days from shipment, or the remainder of the initial warranty period, whichever is longer. Products returned to Polycom must be sent prepaid and packaged appropriately for safe shipment, and it is recommended that they be insured or sent by a method that provides for tracking of the package. Responsibility for loss or damage does not transfer to Polycom until the returned item is received by Polycom. The repaired or replaced item will be shipped to Customer, at Polycom's expense, not later than thirty (30) days after Polycom receives the defective product, and Polycom will retain risk of loss or damage until the item is delivered to Customer.

EXCLUSIONS. Polycom will not be liable under this limited warranty if its testing and examination disclose that the alleged defect or malfunction in the product does not exist or results from:

• Failure to follow Polycom's installation, operation, or maintenance instructions.

• Unauthorized product modification or alteration.

• Unauthorized use of common carrier communication services accessed through the product.

• Abuse, misuse, negligent acts or omissions of Customer and persons under Customer's control; or

• Acts of third parties, acts of God, accident, fire, lighting, power surges or outages, or other hazards.

WARRANTY EXCLUSIVE. IF A POLYCOM PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY FOR BREACH OF THAT WARRANTY SHALL BE REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT POLYCOM'S OPTION. TO THE FULL EXTENT ALLOWED BY LAW, THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, TERMS, OR CONDITIONS,

EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES, TERMS, OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, SATISFACTORY QUALITY, CORRESPONDENCE WITH DESCRIPTION, AND NON-INFRINGEMENT, ALL OF WHICH ARE EXPRESSLY DISCLAIMED. POLYCOM NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS.

SUPPORT & SERVICE AGREEMENTS. If you purchased your product from a Polycom Authorized Reseller, contact the Authorized Reseller for information about support and service agreements applicable to your product. For information on Polycom service, go to the Polycom web site www.polycom.com, products and services menu, or call 1-800-765-9266, outside the US call 1-

408-526-9000, or your local Polycom Office, as listed on the Polycom Web site.

LIMITATION OF LIABILITY. TO THE FULL EXTENT ALLOWED BY LAW, POLYCOM EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING

OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF POLYCOM OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT POLYCOM'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

DISCLAIMER. Some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages for certain products supplied to consumers, or the limitation of liability for personal injury, so the above limitations and exclusions may be limited in their application to you. When the implied warranties are not allowed to be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights which may vary depending on local law.

GOVERNING LAW. This Limited Warranty and Limitation of Liability shall be governed by the laws of the State of California, U.S.A., and by the laws of the United States, excluding their conflicts of laws principles. The United Nations Convention on Contracts for the International Sale of Goods is hereby excluded in its entirety from application to this Limited Warranty and Limitation of Liability.

END-USER LICENSE AGREEMENT FOR POLYCOM SOFTWARE

IMPORTANT - READ CAREFULLY BEFORE USING THE SOFTWARE PRODUCT:

This End-User License Agreement ("Agreement") is a legal agreement between you (either an individual or a single entity) and Polycom, B.V for the POLYCOM® SOFTWARE PRODUCT licensed by Polycom, B.V in Europe, the Middle East, Africa, and Asia Pacific, or the POLYCOM SOFTWARE PRODUCT licensed by Polycom, Inc. in the rest of the world (collectively referred to herein as “POLYCOM”). The SOFTWARE PRODUCT includes computer software as attached hereto and may include associated media, printed materials, and "online" or electronic documentation ("SOFTWARE PRODUCT"). By clicking “I agree” or by installing, copying, or otherwise using the SOFTWARE PRODUCT, you agree to be bound by the terms of this Agreement. If you do not agree to the terms of this Agreement, do not install or use the SOFTWARE PRODUCT, and return it to your place of purchase for a full refund. The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and

treaties. The SOFTWARE PRODUCT is licensed (not sold) to you, and its use is subject to the terms of this Agreement.

1. GRANT OF LICENSE.

Subject to the terms of this Agreement, POLYCOM grants to you a non-exclusive license to install and use the SOFTWARE PRODUCT on the POLYCOM product with which this SOFTWARE PRODUCT is supplied (the “PRODUCT”). You may use the SOFTWARE PRODUCT only in connection with the use of the PRODUCT. You are not permitted to lease, rent, distribute or sublicense the SOFTWARE PRODUCT or to use the SOFTWARE PRODUCT in a time-sharing arrangement or in any other unauthorized manner. Further, no license is granted to you in the human readable code of the SOFTWARE PRODUCT (source code). Except as provided below, this License Agreement does not grant you any rights to patents, copyrights, trade secrets, trademarks, or any other rights in respect to the SOFTWARE PRODUCT.

2. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS.

2.1 Limitations on Reverse Engineering, Decompilation, and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE PRODUCT, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. The SOFTWARE PRODUCT is licensed as a single product. Its component parts may not be separated for use on more than one PRODUCT.

2.2 Back-up. Except as expressly provided for under this Agreement you may not copy the SOFTWARE PRODUCT; except, however, you may keep one copy of the SOFTWARE PRODUCT and, if applicable, one copy of any previous version, for back-up purposes, only to be used in the event of failure of the original. All copies of the SOFTWARE PRODUCT must be marked with the proprietary notices provided on the original SOFTWARE PRODUCT. You may not reproduce the supporting documentation accompanying the SOFTWARE PRODUCT.

2.3 Modifications. You may not modify, translate or create derivative works of the SOFTWARE PRODUCT.

2.4 Proprietary Notices. You may not remove or obscure any proprietary notices on or in the SOFTWARE PRODUCT or the supporting documentation.

2.5 Software Transfer. You may permanently transfer all of your rights under this Agreement, provided you retain no copies, you transfer all of the SOFTWARE PRODUCT (including all component parts, the media and printed materials, any upgrades, this Agreement, and, if applicable, the Certificate of Authenticity), and the recipient agrees to the terms of this Agreement. If the SOFTWARE PRODUCT is an upgrade, any transfer must include all prior versions of the SOFTWARE PRODUCT. However, if the SOFTWARE PRODUCT is marked “Not for Resale” or “NFR”, you may not resell it or otherwise transfer it for value.

2.6 Copyright. All title and copyrights in and to the SOFTWARE PRODUCT (including but not limited to any images, photographs, animations, video, audio, music, text, and "applets" incorporated into the SOFTWARE PRODUCT), the accompanying printed materials, and any copies of the SOFTWARE PRODUCT are owned by POLYCOM or its suppliers. The SOFTWARE PRODUCT is protected by copyright laws and international treaty provisions. Title, ownership rights, and intellectual property rights in the SOFTWARE PRODUCT shall remain in POLYCOM or its suppliers. Title and related rights in the content accessed through the SOFTWARE PRODUCT is the property of such content owner and may be protected by applicable law. This Agreement gives you no rights in such content.

2.7 Confidentiality. The SOFTWARE PRODUCT contains valuable proprietary information and trade secrets of POLYCOM and its suppliers and you shall protect the confidentiality of, and avoid disclosure and unauthorized use of, the SOFTWARE PRODUCT.

2.8 Dual-Media Software. You may receive the SOFTWARE PRODUCT in more than one medium. Regardless of the type or size of medium you receive, you may use only one medium that is appropriate for your single PRODUCT. You may not use or install the other medium on another PRODUCT.

2.9 Reservation. POLYCOM reserves all rights in the SOFTWARE PRODUCT not expressly granted to you in this Agreement.

3. SUPPORT SERVICES.

POLYCOM may provide you with support services related to the SOFTWARE PRODUCT("SUPPORT SERVICES "). Use of SUPPORT SERVICES is governed by the POLYCOM policies and programs described in the POLYCOM - provided materials. Any supplemental software code provided to you as part of the SUPPORT SERVICES is considered part of the SOFTWARE PRODUCT and is subject to the terms and conditions of this Agreement. With respect to technical information you provide to POLYCOM as part of the SUPPORT SERVICES, POLYCOM may use such information for its business purposes, including for product support and development. POLYCOM will not utilize such technical information in a form that personally identifies you.

4. TERMINATION.

Without prejudice to any other rights, POLYCOM may terminate this Agreement if you fail to comply with any of the terms and conditions of this Agreement. In such event, you must destroy all copies of the SOFTWARE PRODUCT and all of its component parts. You may terminate this Agreement at any time by destroying the SOFTWARE PRODUCT and all of its component parts.

5. UPGRADES.

If the SOFTWARE PRODUCT is labeled as an upgrade, you must be properly licensed to use the software identified by POLYCOM as being eligible for the upgrade in order to use the SOFTWARE PRODUCT. A SOFTWARE PRODUCT labeled as an upgrade replaces and/or supplements the software that formed the basis for your eligibility for the upgrade. You may use the resulting upgraded SOFTWARE PRODUCT only in accordance with the terms of this Agreement. If the SOFTWARE PRODUCT is an upgrade of a component of a package of software programs that you licensed as a single product, the SOFTWARE PRODUCT may be used and transferred only as part of that single SOFTWARE PRODUCT package and may not be separated for use on more than one PRODUCT.

6. WARRANTY AND WARRANTY EXCLUSIONS.

6.1 Limited Warranty. POLYCOM warrants that (a) the SOFTWARE PRODUCT will perform substantially in accordance with the accompanying documentation for a period of ninety (90) days from the date of receipt by you, and (b) any SUPPORT SERVICES provided by POLYCOM shall be substantially as described in applicable written materials provided to you by POLYCOM, and POLYCOM support engineers will make commercially reasonable efforts to solve any problem issues. POLYCOM does not warrant that your use of the SOFTWARE PRODUCT will be uninterrupted or error free, or that all defects in the SOFTWARE PRODUCT will be corrected. POLYCOM's sole obligation under this express warranty shall be, at POLYCOM's option and expense, to refund the purchase price paid by you for any defective software product which is returned to POLYCOM with a copy or your receipt, or to replace any defective media with software which substantially conforms to applicable POLYCOM published specifications. Any replacement SOFTWARE PRODUCT will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer.

6.2 Warranties Exclusive. IF THIS SOFTWARE PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, YOUR SOLE REMEDY FOR BREACH OF THAT WARRANTY SHALL BE REPAIR, REPLACEMENT, OR REFUND OF THE PURCHASE PRICE PAID, AT POLYCOM'S OPTION. TO THE FULL EXTENT ALLOWED BY LAW, THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, TERMS, OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES, TERMS, OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, SATISFACTORY QUALITY, CORRESPONDENCE WITH DESCRIPTION, AND NON-INFRINgeMENT, ALL OF WHICH ARE EXPRESSLY DISCLAIMED. POLYCOM NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF THIS SOFTWARE PRODUCT. POLYCOM SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT OR MALFUNCTION IN THE SOFTWARE PRODUCT DOES NOT EXIST OR WAS CAUSED BY YOUR OR ANY THIRD PERSON'S MISUSE, NEGLECT, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO MODIFY THE PRODUCT, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, POWER CUTS OR OUTAGES, OTHER HAZARDS, OR ACTS OF GOD.

7. LIMITATION OF LIABILITY.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL POLYCOM OR ITS SUPPLIERS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE SOFTWARE PRODUCT OR THE PROVISION OF OR FAILURE TO PROVIDE SUPPORT SERVICES, EVEN IF POLYCOM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, POLYCOM'S ENTIRE LIABILITY SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU FOR THE SOFTWARE PRODUCT OR U.S. $5.00. PROVIDED, HOWEVER, IF YOU HAVE ENTERED INTO A POLYCOM SUPPORT SERVICES AGREEMENT, POLYCOM'S ENTIRE LIABILITY REGARDING SUPPORT SERVICES SHALL BE GOVERNED BY THE TERMS OF THAT AGREEMENT.

8. DISCLAIMER.

Some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages for certain products supplied to consumers, or the limitation of liability for personal injury, so the above limitations and exclusions may be limited in their application to you. When the implied warranties are not allowed to be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights which may vary depending on local law.

9. EXPORT CONTROLS.

The SOFTWARE PRODUCT may not be downloaded or otherwise exported or re-exported (i) into (or to a national or resident of) Cuba, Iraq, Libya, North Korea, Yugoslavia, Iran, Syria, Republic of Serbia, or any other country to which the U.S. has embargoed goods; or (ii) to anyone on the U.S. Treasury Department's list of Specially Designated Nationals or the U.S. Commerce Department's Table of Denial Orders. By downloading or using the SOFTWARE PRODUCT, you are agreeing to the foregoing and you are representing and warranting that you are not located in, under the control of, or a national or resident of any such country or on any such list. If you obtained this SOFTWARE PRODUCT outside of the United States, you are also agreeing that you will not export or re-export it in violation of the laws of the country in which it was obtained.

10. MISCELLANEOUS.

10.1 Governing Law. This Agreement shall be governed by the laws of the State of California as such laws are applied to agreements entered into and to be performed entirely within California between California residents, and by the laws of the United States. The United Nations Convention on Contracts for the International Sale of Goods (1980) is hereby excluded in its entirety from application to this Agreement.

10.2 General. This Agreement represents the complete agreement concerning this license and may amended only by a writing executed by both parties. If any provision of this Agreement is held to be unenforceable, such provision shall be reformed only to the extent necessary to make it enforceable.

10.3 Contact. If you have any questions concerning this Agreement, or if you desire to contact POLYCOM for any reason, please contact the POLYCOM office serving your country.

— 10.4 U.S. Government Restricted Rights. The SOFTWARE PRODUCT and documentation are provided with RESTRICTED RIGHTS. The SOFTWARE PRODUCT programs and documentation are deemed to be "commercial computer software" and "commercial computer software documentation", respectively, pursuant to DFAR Section 227.7202 and FAR 12.212(b), as applicable. Any use, modification, reproduction, release, performance, display or disclosure of the SOFTWARE PRODUCT programs and/or documentation by the U.S. Government or any of its agencies shall be governed solely by the terms of this Agreement and shall be prohibited except to the extent expressly permitted by the terms of this Agreement. Any technical data provided that is not covered by the above provisions is deemed to be "technical data-commercial items" pursuant to DFAR Section 227.7015(a). Any use, modification, reproduction, release, performance, display or disclosure of such technical data shall be governed by the terms of DFAR Section 227.7015(b).

©2012 Polycom, Inc. All rights reserved.

Specifications subject to change without notice.

Polycom Headquarters

4750 Willow Road
Pleasanton
CA 94588 (T)

Polycom (Denmark)

Langmarksvej 34
DK-8700 Horsens
Tel. +45 7560 2850
Fax +45 7560 2851
emeadk@polycom.com
www.polycom.com

14211600-HD ED.1